



CLUB VINYL SHORT TONNEAU COVER

Standard black vinyl 'short' tonneau cover, fitting right hand drive MGA models where the tonneau cover fastens just behind the rear cockpit rail. For 'long' tonneau covers fixing to the hood retaining lugs at the rear of the rear deck, refer to the other items in this section of the website. Please contact MGOC Spares for ordering details on left hand drive tonneau covers.

There are no rules as to which years of MGA require which length of tonneau cover - long and short styles were used during most years of production, although it seems early 1500s were only fitted with the short style. Check your car before ordering - a line of Lift The Dot pegs just behind the rear cockpit rail means a short cover is required, whereas if there are only the hood fastening pegs further back on the rear deck the long cover should be fitted.

Club MGA tonneau covers are supplied with all fasteners unfitted, allowing owners to take account of the slight differences that are found sometimes in fastener positions on earlier MG cars.



Easy to fit. Ensure the cover is warm (but not hot) when fitting in colder weather - a 1kW fan heater in the car works well. Align the cover by marking centres front and rear on both cover and car. Working outwards from the centre of the car, one at a time and alternately on one side then the other, mark each fastener position with chalk and fix the fastener to the cover. Do the rear deck first, then the fascia.



Basic hand tools required. Craft knife, chalk for centre marks and fastener locations, tape measure, craft knife, punch pliers (optional), small flat blade screwdriver to bend over fastener tags to secure fasteners to cover.

MORE GREAT RECOMMENDATIONS:



**RENOVO VINYL CLEANER
(500ml)**



**RENOVO VINYL PROTECTOR
(500ml)**



**STAINLESS BOLT-ON
BOOT RACK MGA**