



SEAT BACKBOARD MIDGET

This style of seat backboard was fitted to all Midget and Sprite front seats throughout the 1970s and featured cut-outs to fit around the reclining mechanisms. The Club seat backboard is exactly to original MG specification, guaranteeing perfect fit and performance in your Midget or Sprite.

The main tasks of the seat backboard are to tension the back panel of the seat back (or squab) cover and to prevent the seat's substructure and frame from disfiguring the back panel. Seat backboards are sometimes overlooked during a seat rebuild - a mistake, since the backboard is usually quite out of shape by the time the seat becomes due for reupholstering.

Another item along with new seat foams and a diaphragm that really should be on the shopping list when reupholstering a Midget or Sprite front seat.



Easy to fit. The backboard simply attaches to the rear of the seat squab frame with adhesive tape. The backboard is gently fashioned into a curved profile around the back of the frame while doing so. On many seats, a couple of self-tapping screws are used first to anchor the board in place on the frame.



Basic hand tools required. Crosshead screwdriver, if required, for anchoring screws. Adhesive tape to attach board to frame.

MORE GREAT RECOMMENDATIONS:



**SEAT FOAM BACK
MIDGET 1970-79**



**SEAT FOAM BASE
MIDGET 1970-79**



SEAT DIAPHRAGM MIDGET