



RUBBER FOOTWELL MATS MIDGET

Faithful reproduction of the original MG dealer-supplied rubber mats, with 'MG Midget' graphic.

Designed to fit all Midget models, these heavy duty and accurately moulded footwell mats keep carpets clean and free from grit while protecting against heel wear.

Also make an ideal and practical winter replacement for footwell carpets if your car sees frequent use during the wetter months of the year.

A very simple accessory that works, looks great and adds to the period feel of your Midget.

01954 231318



Easy to fit. Cut out specially marked areas for accelerator pedal and dipswitch (pre-1970 only) on driver's side for fitment in chrome bumper Midgets. No trimming required for use in rubber bumper Midget - just put them in the car.



Basic hand tools required. Craft knife to trim driver's side mat in chrome bumper Midgets. No tools required for rubber bumper cars.

MORE GREAT RECOMMENDATIONS:



BOOT RACK
STAINLESS OR CHROME



MUDFLAPS
(CHOICE OF STYLES)



RADIO CONSOLE
ORIGINAL FITMENT STYLE